

LT50/LTM50-CB



WITH HIGH FREQUENCY
高频

MACHINE TORCH
自动枪

18.1 1/4G

18.2 M14X1.5

18.3 M16X1.5

18.4 Central adaptor
中央插头

19

Technical	Data 技术参数
Current 额定电流	50 Amp
Duty Cycle 占载率	60%
Gas 气体	AIR 空气
Gas Pressure 气压	4.5-5.0 Bar
Gas Flow 气流量	120LPM
Ignition 引弧方式	HF 高频
Post Flow 气体延时	50 sec. recommended 推荐50秒
Standard Length 标准长度	6M

LT50/LTM50-CB



HAND TORCH

Code	Ref.	Description
IVT6800	1526	Plasma cutting torch LT50/6m 1/8G;等离子切割枪/LT50/6m 1/8G
IVT6805		Plasma cutting torch LT50/6m 1/4G;等离子切割枪/LT50/6m 1/4G
IVT6806		Plasma cutting torch LT50/6m M14 × 1.5;等离子切割枪/LT50/6m/M14 × 1.5
IVT6809		Plasma cutting torch LT50/6m M16 × 1.5;等离子切割枪/LT50/6m/M16 × 1.5
IVT6807	1574	Plasma cutting torch LT50/6m central adaptor;等离子切割枪/LT50/6m/中央插头

MACHINE TORCH

Code	Ref.	Description
IVT6730		Plasma cutting auto torch LTM50/6m 1/8G;等离子切割枪/LTM50/6m 1/8G
IVT6722		Plasma cutting auto torch LTM50/6m 1/4G;等离子切割枪/LTM50/6m 1/4G
IVT6723		Plasma cutting auto torch LTM50/6m M14 × 1;等离子切割枪/LTM50/6m/M14 × 1
IVT6724		Plasma cutting auto torch LTM50/6m M16 × 1.5;等离子切割枪/LTM50/6m/M16 × 1.5
IVT6736		Plasma cutting auto torch LTM50/6m central adaptor;等离子切割枪/LTM50/6m/中央插头

Position	Code	Ref.	Description
(带“●”为标准配置 / With “●” is the standard configuration)			
● 1	ISM0603		Spacer spring/LT50; 隔离簧/LT50
2	ISM0006		Shield cap for extended tip/LT50;长接触切割保护帽/LT50
3			Outside nozzle;外喷嘴
3.1	IVS0008-03	5.710.121	Outside nozzle/bakelite/LT50;外喷嘴/黑色胶木/LT50
● 3.2	IVS0008-05		Outside nozzle/maximum life/gray glass fiber/LT50;外喷嘴/长寿命/灰色玻纤/LT50
4	IVU0069-10	1306	Extended conical tip φ 1.0mm/LT50;加长锥形喷嘴 φ 1.0mm/LT50
5			Extended tip;加长喷嘴
5.1	IVU0019-10	1370	Extended tip φ 1.0mm/LT50;加长喷嘴 φ 1.0mm/LT50
5.2	IVU0018-10	1395	Extended tip φ 1.0mm/LT50-70;加长喷嘴 φ 1.0mm/LT50-70
5.3	IVU0018-11		Extended tip φ 1.1mm/LT50-70;加长喷嘴 φ 1.1mm/LT50-70
6	IVU0064-10	1305	Conical tip φ 1.0mm/LT50-70;锥形喷嘴 φ 1.0mm/LT50-70
7			Tip;喷嘴
● 7.1	IVU0033-10	1396	Tip φ 1.0mm/LT50-70/L=12.3mm;喷嘴 φ 1.0mm/LT50-70/L=12.3mm
7.2	IVU0033-11		Tip φ 1.1mm/LT50-70/L=12.3mm;喷嘴 φ 1.1mm/LT50-70/L=12.3mm
7.3	IVU0033-12		Tip φ 1.2mm/LT50-70/L=12.3mm;喷嘴 φ 1.2mm/LT50-70/L=12.3mm
7.4	IVU0065-10	1304	Tip φ 1.0mm/LT50-70/L=11.2mm;喷嘴 φ 1.0mm/LT50-70/L=11.2mm
8	IVF0002		Diffuser LT50-70; 分流器 LT50-70
9	IVB0015	1518-HF	Extended electrode HF Plasma LT50;加长等离子电极/HF/LT50
● 10	IVB0062	1521-HF	Electrode HF Plasma LT50;等离子电极/HF/LT50
11	IVZ0050		Plasma torch head LT50;等离子枪头 LT50
11a	IFT0707		"O"ring φ 12.42×1.78mm in silicon red; O型圈 φ 12.42×1.78mm/硅胶/红色
12	IGV0039		Plasma handle manual/CB50-70/Red;等 离子 手工 手柄/CB50-70/红色
13	IHJ0722		Protection part/Plasma/Yellow;开 关 保护 档片/等 离子 用/黄色
14	IHQ0070	185.0031	Trigger;开 关
15	IHJ0893		Joint/small/new type;球 节 套 件/小/新 式
16			Cable assembly;电缆组
16.1	IVN00006066-00		Cable assembly/LT50-70/6MMQ/6M ATT.1/8G;电缆组/LT50-70/6MMQ/6M ATT.1/8G
16.2	IVN00006060-00		Cable assembly/LT50-70/6MMQ/6M CENTER ADAPTOR;电缆组/LT50-70/6MMQ/6M中央插头
16.3	IVN10006060-00		Cable assembly/LTM50-70/6MMQ/6M CENTER ADAPTOR;电缆组/LTM50-70/6MMQ/6M中央插头
16.4	IVN10006066-00		Cable assembly/LTM50-70/6MMQ/6M ATT.1/8G;电缆组/LTM50-70/6MMQ/6M ATT.1/8G
17	IVZ0085		Plasma torch head LTM50;等离子枪头 LTM50
17a	IGV0013		Fiber glass position tube/LTM;自动枪手柄 LTM
18			Adaptor;接头
18.1	IZT5687		Connecting adaptor 1/8G-1/4G;转换接头1/8G-1/4G
18.2	IZT5685		Connecting adaptor 1/8G-M14×1;转换接头1/8G-M14×1.5
18.3	IZT5689		Connecting adaptor 1/8G-M16×1.5;转换接头1/8G-M16×1.5
18.4	IZX0078		Central adaptor torch side Plasma 5 pins;等 离子 中央 插头/5针
19	ISM0081		Circle cutting attachment/LT50;圆周切割附件 LT50
19.1	ISM0082	166	Wheel spacer with spanner/LT50;滚轮支架/LT50

LT70/LTM70-CB



WITH HIGH FREQUENCY
高频

MACHINE TORCH
自动枪

Technical Data	技术参数
Current 额定电流	70 Amp
Duty Cycle 占载率	60%
Gas 气体	AIR 空气
Gas Pressure 气压	4.5-5.0 Bar
Gas Flow 气流量	130LPM
Ignition 引弧方式	HF 高频
Post Flow 气体延时	70 sec. recommended 推荐70秒
Standard Length 标准长度	6M

Note: About the registered trade mark, reference number of the model of the machine and spare parts, please see inner cover (company introduction)
注:关于注册商标、机器及配件的参考编号的注解, 请见封面内页 (公司简介)

LT70/LTM70-CB



HAND TORCH

Code	Ref.	Description
IVT6870	1564	Plasma cutting torch LT70/6m 1/8G;等离子切割枪/LT70/6m 1/8G
IVT6876		Plasma cutting torch LT70/6m 1/4G;等离子切割枪/LT70/6m 1/4G
IVT6875		Plasma cutting torch LT70/6m M16 × 1.5;等离子切割枪/LT70/6m/M16 × 1.5
IVT6877	1573	Plasma cutting torch LT70/6m central adaptor;等离子切割枪/LT70/6m/中央插头

MACHINE TORCH

Code	Ref.	Description
IVT6740	1563	Plasma cutting auto torch LTM70/6m 1/8G;等离子切割枪/LTM70/6m 1/8G
IVT6742		Plasma cutting auto torch LTM70/6m 1/4G;等离子切割枪/LTM70/6m 1/4G
IVT6744		Plasma cutting auto torch LTM70/6m M16 × 1.5;等离子切割枪/LTM70/6m/M16 × 1.5
IVT6746	1566	Plasma cutting auto torch LTM70/6m central adaptor;等离子切割枪/LTM70/6m/中央插头

Position	Code	Ref.	Description
(带“●”为标准配置 / With “●” is the standard configuration)			
1	ISM6662	1405	Double pointed spacer/LT70;两点支架 LT70
● 2	ISM0060	1394	Spacer spring/LT70; 隔离簧/LT70
3	ISM0007		Shield cap for Extended tip/LT70;长接触切割保护帽 LT70
4			Outside nozzle;外喷嘴
4.1	IVS0087-03	5.710.191	Outside nozzle/bakelite/LT70;外喷嘴/黑色胶木/LT70
● 4.2	IVS0087-05		Outside nozzle/maximum life/gray glass fiber/LT70;外喷嘴/长寿命/灰色玻纤/LT70
5			Tip;喷嘴
5.1	IVU0065-09	1309	Tip Φ 0.9mm/LT50-70/L=11.2mm;喷嘴 Φ 0.9mm/LT50-70/L=11.2mm
5.2	IVU0033-10	1396	Tip Φ 1.0mm/LT50-70/L=12.3mm;喷嘴 Φ 1.0mm/LT50-70/L=12.3mm
5.3	IVU0033-11		Tip Φ 1.1mm/LT50-70/L=12.3mm;喷嘴 Φ 1.1mm/LT50-70/L=12.3mm
● 5.4	IVU0033-12		Tip Φ 1.2mm/LT50-70/L=12.3mm;喷嘴 Φ 1.2mm/LT50-70/L=12.3mm
6			Tip;喷嘴
6.1	IVU0028-10		Flat tip Φ 1.0mm;扁平喷嘴 Φ 1.0mm/ LT50-70
6.2	IVU0028-12		Flat tip Φ 1.2mm;扁平喷嘴 Φ 1.2mm/ LT50-70
7			Tip;喷嘴
7.1	IVU0064-10	1305	Conical tip Φ 1.0mm/LT50-70;锥形喷嘴 Φ 1.0mm/ LT50-70
7.2	IVU0064-12		Conical tip Φ 1.2mm/LT50-70;锥形喷嘴 Φ 1.2mm/ LT50-70
8			Tip;喷嘴
8.1	IVU0035-98	1366	Extended tip Φ 0.98mm/LT50-70;加长喷嘴 Φ 0.98mm/ LT50-70
8.2	IVU0018-10	1395	Extended tip Φ 1.0mm/LT50-70;加长喷嘴 Φ 1.0mm/ LT50-70
8.3	IVU0018-11		Extended tip Φ 1.1mm/LT50-70;加长喷嘴 Φ 1.1mm/ LT50-70
8.4	IVU0018-12		Extended tip Φ 1.2mm/LT50-70;加长喷嘴 Φ 1.2mm/ LT50-70
9	IVF0002		Diffuser LT50-70;分流器 LT50-70
10	IVB0018	1402	Electrode HF Plasma LT70;等离子电极 LT70
11	IVB0019	1368	Extended electrode HF Plasma LT70;加长等离子电极 LT70
12	IZN0766	3.065.204	Air tube/LT70;导流管/LT70
13	IVZ0015		Plasma torch head LT70;等离子枪头 LT70
13a	IFT0707		"O"ring Φ 12.42x1.78mm in silicon red;O型圈 Φ 12.42x1.78mm/硅胶/红色
14	IGV0039		Plasma handle manual/CB50-70/Red;等离子手工手柄/CB50-70/红色
15	IHJ0722		Protection part/Plasma/Yellow;开关保护档片/等离子用/黄色
16	IHQ0070	185.0031	Trigger;开关
17	IHJ0893		Joint/small/new type;球节套件/小/新式
18			Cable assembly;电缆组
18.1	IVN00006066-00		Cable assembly /LT50-70/6MMQ/6M ATT.1/8G;电缆组/LT50-70/6MMQ/6M ATT.1/8G
18.2	IVN00006060-00		Cable assembly /LT50-70/6MMQ/6M center adaptor;电缆组/LT50-70/6MMQ/6M/中央插头
18.3	IVN10006060-00		Cable assembly /LT50-70/6MMQ/6M central adaptor;电缆组/LT50-70/6MMQ/6M/中央插头
18.4	IVN10006066-00		Cable assembly /LTM50-70/6MMQ/6M ATT.1/8G;电缆组/LTM50-70/6MMQ/6M ATT.1/8G
19	ICG6006		Spanner for Plasma;等离子枪扳手
20	IVZ0073	1349	Plasma torch head LTM70;等离子枪头 LTM70
20a	IGV0013		Fiber glass position tube/LTM;自动枪手柄 LTM
21			Adaptor;接头
21.1	IZT5687		Connecting adaptor 1/8G-1/4G;转换接头 1/8G-1/4G
21.2	IZT5689		Connecting adaptor 1/8G-M16 × 1.5;转换接头 1/8G-M16 × 1.5
21.3	IZX0078		Central adaptor torch side Plasma 5 pins;等离子中央插头/5针
22	ISM0029		Circle cutting attachment/LT70;圆周切割附件/LT70
22.1	ISM0028		Wheel spacer with spanner/LT70;滚轮支架/LT70

Note: About the registered trade mark, reference number of the model of the machine and spare parts, please see inner cover (company introduction)
注:关于注册商标、机器及配件的参考编号的注解, 请见封面内页 (公司简介)

LT81/LTM81-A



WITH HIGH FREQUENCY
高频

MACHINE TORCH
自动枪

19.1 1/4G

19.2 3/8G

19.3 M14X1.5

19.4 M16X1.5

19.5 Central adaptor
中央插头

Technical Data	技术参数
Current 额定电流	80 Amp
Duty Cycle 占载率	60%
Gas 气体	AIR 空气
Gas Pressure 气压	4.5-5.0 Bar
Gas Flow 气流量	160LPM
Ignition 引弧方式	HF 高频
Post Flow 气体延时	80 sec. recommended 推荐80秒
Standard Length 标准长度	6M

Note: About the registered trade mark, reference number of the model of the machine and spare parts, please see inner cover (company introduction)
注:关于注册商标、机器及配件的参考编号的注解, 请见封面内页 (公司简介)

LT81/LTM81-A



HAND TORCH

Code	Ref.	Description
IVT6900	PA1400	Plasma cutting torch LT81/6m 3/8G;等离子切割枪/LT81/6m 3/8G
IVT6901		Plasma cutting torch LT81/6m M14 × 1.5;等离子切割枪/LT81/6m M14 × 1.5
IVT6905		Plasma cutting torch LT81/6m M16 × 1.5;等离子切割枪/LT81/6m M16 × 1.5
IVT6907	PA1402	Plasma cutting torch LT81/6m central adaptor;等离子切割枪/LT81/6m/中央插头
IVT6909	PA1404	Plasma cutting torch LT81/6m 1/4G;等离子切割枪/LT81/6m 1/4G

MACHINE TORCH

Code	Ref.	Description
IVT0630		Plasma cutting auto torch LTM81/6m 3/8G;等离子切割枪/LTM81/6m 3/8G
IVT0636		Plasma cutting auto torch LTM81/6m central adaptor;等离子切割枪/LTM81/6m 中央插头
IVT0706		Plasma cutting auto torch LTM81/6m 1/4G;等离子切割枪/LTM50/6m 1/4G
IVT0707		Plasma cutting auto torch LTM81/6m M16 × 1.5;等离子切割枪/LTM81/6m/M16 × 1.5
IVT0708		Plasma cutting auto torch LTM81/6m M14 × 1.5;等离子切割枪/LTM50/6m M14 × 1.5

Position	Code	Ref.	Description
(带“●”为标准配置 / With "●" is the standard configuration)			
1	ISM0706	CV0201	Spacer for contact cutting/LT81;隔离支架/接触切割 LT81
2	ISM0088	CV0033	Four pointed spacer/LT81;四点支架/LT81
●3	ISM0073	CV0028	Spacer spring/LT81; 隔离簧/LT81
4			Outside nozzle;外喷嘴
4.1	IVS0665-03	PC0115	Outside nozzle/bakelite/LT81;外喷嘴/黑色胶木/LT81
●4.2	IVS0665-05		Outside nozzle/maximum life/gray glass fiber/LT81;外喷嘴/长寿命/灰色玻纤/LT81
5			Tip;喷嘴
5.1	IVU0605-10	PD0105-10	Tip Φ 1.0mm LT81;喷嘴 Φ 1.0mm/LT81
5.2	IVU0605-11	PD0105-11	Tip Φ 1.1mm LT81;喷嘴 Φ 1.1mm/LT81
●5.3	IVU0605-12	PD0105-12	Tip Φ 1.2mm LT81;喷嘴 Φ 1.2mm/LT81
6			Tip;喷嘴
6.1	IVU0601-10	PD0106-10	Extended tip Φ 1.0mm LT81;加长喷嘴 Φ 1.0mm/ LT81
6.2	IVU0601-12	PD0106-12	Extended tip Φ 1.2mm LT81;加长喷嘴 Φ 1.2mm/ LT81
●7	IVF0602	PE0107	Diffuser LT81;分流器 LT81
8	IVB0604	FH0560	Electrode Plasma LT81; 等离子电极 LT81
9	IZN0510	PR0109	Air tube/LT81;导流管 LT81
10	IVB0665	PR0115	Extended electrode Plasma LT81;加长等离子电极 LT81
11	IZN0516	FH0561	Extended air tube/LT81;加长导流管 LT81
12	IVZ0690		Plasma torch head LT81;等离子枪头 LT81
12a	IFT0675	EA0125	"O"ring Φ 15.6x1.78mm in silicon;O型圈 Φ 15.6x1.78mm/硅胶
13	IGV0035		Plasma handle manual/A Series/Red;等离子手工手柄/A系列/红色
14	IHJ0722		Protection part/Plasma/Yellow;开关保护档片/等离子用/黄色
15	IHQ0070	185.0031	Trigger;开关
16	IHJ0893		Joint/small/new type;球节套件/小/新式
17			Cable assembly;电缆组
17.1	IVN00108066-00		CABLE ASSEMBLY/LT81/8MMQ/6M ATT. 1/8G;电缆组/LT81/8MMQ/6M ATT. 1/8G
17.2	IVN00108060-00		CABLE ASSEMBLY/LT81/8MMQ/6M CENTER ADAPTOR;电缆组/LT81/8MMQ/6M 中央插头
17.3	IVN10108066-00		CABLE ASSEMBLY/LTM81/8MMQ/6M ATT. 1/8G;电缆组/LTM81/8MMQ/6M ATT. 1/8G
17.4	IVN10108060-00		CABLE ASSEMBLY/LTM81/8MMQ/6M CENTER ADAPTOR;电缆组/LTM81/8MMQ/6M 中央插头
18	IVZ0670	PF0120	Plasma torch head LTM81;等离子枪头 LTM81
18a	IGV0018	W0300144	Fiber glass position tube/LTM;自动枪手柄 LTM
19			Adaptor;接头
19.1	IZT5687		Connecting adaptor 1/8G-1/4G;转换接头1/8G-1/4G
19.2	IZT5686		Connecting adaptor 1/8G-3/8G;转换接头1/8G-3/8G
19.3	IZT5685		Connetecing adaptor 1/8G-M14X1.5;转换接头1/8G-M14X1.5
19.4	IZT5689		Connecting adaptor 1/8G-M16×1.5;转换接头1/8G-M16×1.5
19.5	IZX0078	FY0023	Central adaptor torch side Plasma 5 pins;等离子中央插头/5针
20	ISM0057		Circle cutting attachment/LT81;圆周切割附件/LT81
20.1	ISM0056		Wheel spacer with spanner A81/S75;滚轮支架 A81/S75/带扳手

Note: About the registered trade mark, reference number of the model of the machine and spare parts, please see inner cover (company introduction)
注:关于注册商标、机器及配件的参考编号的注解, 请见封面内页 (公司简介)

LT100/LTM100-CB



WITH HIGH FREQUENCY
高频

MACHINE TORCH
自动枪

26a

26

27.1

1/4G

27.2

M14X1

27.3

M16X1.5

27.4

Central adaptor
中央插头

25

28.1

28

Technical Data	技术参数
Current 额定电流	100 Amp
Duty Cycle 占载率	60%
Gas 气体	AIR 空气
Gas Pressure 气压	4.5-5.0 Bar
Gas Flow 气流量	180LPM
Ignition 引弧方式	HF 高频
Post Flow 气体延时	100sec. recommended 推荐100秒
Standard Length 标准长度	6M

Note: About the registered trade mark, reference number of the model of the machine and spare parts, please see inner cover (company introduction)
注:关于注册商标、机器及配件的参考编号的注解, 请见封面内页 (公司简介)

LT100/LTM100-CB



HAND TORCH

Code	Ref.	Description
IVT6850		Plasma cutting torch LT100/6m 1/8G;等离子切割枪/LT100/6m 1/8G
IVT6856		Plasma cutting torch LT100/6m 1/4G;等离子切割枪/LT100/6m 1/4G
IVT6858		Plasma cutting torch LT100/6m M14 × 1;等离子切割枪/LT100/6m/M14 × 1
IVT6859		Plasma cutting torch LT100/6m M16 × 1.5;等离子切割枪/LT100/6m/M16 × 1.5
IVT6857		Plasma cutting torch LT100/6m central adaptor;等离子切割枪/LT100/6m/中央插头

MACHINE TORCH

Code	Ref.	Description
IVT6761		Plasma cutting auto torch LTM100/6m 1/8G;等 离子自动切割枪/LTM100/6m 1/8G
IVT6762		Plasma cutting auto torch LTM100/6m M14×1;等 离子自动切割枪/LTM100/6m/M14×1
IVT6763		Plasma cutting auto torch LTM100/6m M16×1.5;等 离自动子切割枪/LTM100/6m/M16×1.5
IVT6765		Plasma cutting auto torch LTM100/6m central adaptor;等 离子自动切割枪/LTM100/6m/中央插头
IVT6766		Plasma cutting auto torch LTM100/6m 1/4G;等 离子自动切割枪/LTM100/6m 1/4G

Position	Code	Ref.	Description
(带“●”为标准配置 / With “●” is the standard configuration)			
1	ISM0069	W0300177	Four pointed spacer/LT100-150;四点支架 LT100-150
2	ISM0067	1408 / W0300131	Double pointed spacer/LT100-150; 两点支架LT100-150
● 3	ISM0066	W0300130	Spacer spring LT100-150; 隔离簧LT100-150
● 4	IVS0082-05	W0300129	Outside nozzle LT100/grey;外喷嘴 LT100/灰色
5			Tip;喷嘴
5.1	IVU0071-11	1371 / W0300125	Tip Φ 1.1mm LT100-150;喷嘴 Φ 1.1mm/ LT100-150
● 5.2	IVU0071-13	1372 / W0300174	Tip Φ 1.3mm LT100-150;喷嘴 Φ 1.3mm/ LT100-150
5.3	IVU0071-16	1373 / W0300175	Tip Φ 1.6mm LT100-150;喷嘴 Φ 1.6mm/ LT100-150
6	ISM0099	W0300184	Locking nut;锁紧螺母
7	ISM0083	W0300180	Spacer for contact cutting/LT100-150;隔离支架/接触切割 LT100-150
8	IVS0083-05	W0300138	Contact nozzle retaining cap/LT100/grey;接触式外喷嘴/LT100/灰色
9			Tip;喷嘴
9.1	IVU0073-13	W0300135	Flat tip Φ 1.35mm/LT100-150;扁平喷嘴Φ1.35mm/LT100-150
9.2	IVU0073-16	W0300137	Flat tip Φ 1.6mm/LT100-150;扁平喷嘴Φ1.6mm/LT100-150
● 10	IVF0004	1377 / W0300124	Diffuser LT100-150;分流器 LT100-150
● 11	IVB0089	1376 / W0300123	Electrode HF LT100-150;等离子电极 HF/LT100-150
● 12	IZN0769	W0300122	Air tube/LT100;导流管 LT100
13	ISM0003	W0300182	Shield cap hand tip (Max 50A)/LT100-151;接触切割保护帽(最大50A) LT100-151
14	ISM0004	W0300183	Spacer for contact cutting hand tip /LT100-151;加长接触切割保护帽/LT100-151
15			Tip;喷嘴
15.1	IVU0075-13	W0300178	Extended tip Φ 1.3mm/LT100-150;加长喷嘴 Φ 1.3mm/ LT100-150
15.2	IVU0075-16	W0300179	Extended tip Φ 1.6mm/LT100-150;加长喷嘴 Φ 1.6mm/ LT100-150
15.3	IVU0075-18		Extended tip Φ 1.8mm/LT100-150;加长喷嘴 Φ 1.8mm/ LT100-150
15.4	IVU0080-11	1369 / W0300134	Contact extended tip /LT100-150;接触加长喷嘴 /LT100-150
16	IVB0095	1517 / W0300133	Extended electrode HF Plasma LT100-150;加长等离子电极 HF/LT100-150
17	IZN0762		Extended air tube/LT100;加长导流管 LT100
18	IVF9006		Front insulator/LT100-101;枪颈前端绝缘圈 LT100-101
19	IVZ0025		Plasma torch head LT100;等离子枪头 LT100
19a	IFT0689	1398 / W0300121	“O”ring LT100;O型圈 LT100
20	IGV0035		Plasma handle manual/A Series/Red;等离子手工手柄/A系列/红色
21	IHJ0722		Protection part/Plasma/Yellow;开关保护档片/等离子用/黄色
22	IHQ0070	185.0031	Trigger;开关
23	IHJ0894		Joint/big/new type;球节套件/大/新式
24			Cable assembly;电缆组
24.1	IVN00210066-00		Cable assembly/LT100-101/10MMQ/6M ATT. 1/8G;电缆组/LT100-101/10MMQ/6M ATT. 1/8G
24.2	IVN00210060-00		Cable assembly/LT100-101/10MMQ/6M central adaptor;电缆组/LT100-101/10MMQ/6M 中央插头
24.3	IVN10210066-00		Cable assembly/LTM100-101/10MMQ/6M ATT. 1/8G;电缆组/LTM100-101/10MMQ/6M ATT. 1/8G
24.4	IVN10210060-00		Cable assembly/LTM100-101/10MMQ/6M central adaptor;电缆组/LTM100-101/10MMQ/6M 中央插头
25	ICG6006		Spanner for Plasma;等离子枪扳手
26	IVZ0082	W0300143	Plasma torch head LTM100;等离子枪头 LTM100
26a	IGV0013	W0300144	Fiber glass position tube/LTM;自动枪手柄 LTM
27			Adaptor;接头
27.1	IZT5687		Connecting adaptor 1/8G-1/4G;转换接头1/8G-1/4G
27.2	IZT5688		Connecting adaptor 1/8G-M14×1;转换接头1/8G-M14×1
27.3	IZT5689		Connecting adaptor 1/8G-M16×1.5;转换接头1/8G-M16×1.5
27.4	IZX0078		Central adaptor torch side Plasma 5 pins;等离子中央插头/5针
28	ISM0077	169	Circle cutting attachment/LT100-151;圆周切割附件 LT100-151
28.1	ISM0076		Wheel spacer with spanner LT100-101;滚轮支架 LT100-101/带扳手

Note: About the registered trade mark, reference number of the model of the machine and spare parts, please see inner cover (company introduction)
注:关于注册商标、机器及配件的参考编号的注解, 请见封面内页 (公司简介)

LT101/LTM101-A



WITH HIGH FREQUENCY
高频

MACHINE TORCH
自动枪

25.1 1/4G

25.2 3/8G

25.3 M14X1

25.4 M16X1.5

25.5 Central adaptor
中央插头

23

26

26.1

Technical Data	技术参数
Current 额定电流	100 Amp
Duty Cycle 占载率	60%
Gas 气体	AIR 空气
Gas Pressure 气压	4.5-5.0 Bar
Gas Flow 气流量	180LPM
Ignition 引弧方式	HF 高频
Post Flow 气体延时	100sec. recommended 推荐100秒
Standard Length 标准长度	6M

LT101/LTM101-A



HAND TORCH

Code	Ref.	Description
IVT6950	PA1450	Plasma cutting torch LT101/6m M14×1;等离子切割枪/LT101/6m M14×1
IVT6956		Plasma cutting torch LT101/6m 3/8G;等离子切割枪/LT101/6m 3/8G
IVT6957	PA1452	Plasma cutting torch LT101/6m central adaptor;等离子切割枪/LT101/6m 中央插头
IVT6958		Plasma cutting torch LT101/6m M16×1.5;等离子切割枪/LT101/6m M16×1.5
IVT6959		Plasma cutting torch LT101/6m 1/4G;等离子切割枪/LT101/6m 1/4G

MACHINE TORCH

Code	Ref.	Description
IVT0660	PA0110	Plasma cutting auto torch LTM101/6m M14×1;等 离子自动切割枪/LTM101/6m/M14×1
IVT0666	PA0111	Plasma cutting auto torch LTM101/6m central adaptor;等 离子自动切割枪/LTM101/6m/中央插头
IVT0681		Plasma cutting auto torch LTM101/6m 1/4G;等 离子自动切割枪/LTM101/6m 1/4G
IVT0682		Plasma cutting auto torch LTM101/6m 3/8G;等 离子自动切割枪/LTM101/6m 3/8G
IVT0683		Plasma cutting auto torch LTM101/6m M16×1.5;等 离子自动切割枪/LTM101/6m/M16×1.5

Position	Code	Ref.	Description
(带“●”为标准配置 / With “●” is the standard configuration)			
1	ISM0069	CV0014	Four pointed spacer/LT100-150;四点支架 LT100-150
2	ISM0067	CV0012	Double pointed spacer/LT100-150;两点支架 LT100-150
●3	ISM0066	CV0011	Spacer spring LT100-150; 隔离簧 LT100-150
●4	IVS0666-05	PC0111	Outside nozzle LT101/GREY;外喷嘴 LT101/灰色
5	ISM0084	CV0039	Four point crown shield with insulator/LT101-141;四点支架/带绝缘环 LT101-141
6	ISM0078	CV0023	Spacer for contact cutting/LT101-141;隔离支架/接触切割 LT101-141
7	IVS0680-05	PC0130	Contact nozzle retaining cap/LT101/grey;接触式外喷嘴/LT101/灰色
8			Tip;喷嘴
8.1	IVU0606-11	PD0101-11	Tip Φ 1.1mm LT101-141;喷嘴 Φ 1.1mm/ LT101-141
●8.2	IVU0606-14	PD0101-14	Tip Φ 1.4mm LT101-141;喷嘴 Φ 1.4mm/ LT101-141
8.3	IVU0606-17	PD0101-17	Tip Φ 1.7mm LT101-141;喷嘴 Φ 1.7mm/ LT101-141
●9	IVF0606	PE0101	Diffuser LT101-141;分流器 LT101-141
●10	IVB0606	PR0101	Electrode Plasma LT101-141;等离子电极 LT101-141
11	IZN0517		Air tube/LT100-101;导流管 LT100-101
12	ISM0099	W0300184	Locking nut;锁紧螺母
13	ISM0003	CV0008	Contact cutting attachment/LT101-151;接触切割保护帽 LT100-151
14	ISM0004	CV0009	Long contact cutting attachment/LT101-151;加长接触切割保护帽 LT100-151
15			Tip;喷嘴
15.1	IVU0662-11		Extended tip Φ 1.1mm LT101-151; 加长喷嘴 Φ 1.1mm LT101-151
15.2	IVU0662-14	PD0117-14	Extended tip Φ 1.4mm LT101-151; 加长喷嘴 Φ 1.4mm LT101-151
15.3	IVU0662-17	PD0117-17	Extended tip Φ 1.7mm LT101-151; 加长喷嘴 Φ 1.7mm LT101-151
15.4	IVU0666		Extended tip Φ 1.2mm 50A/LT101-151; 加长喷嘴 Φ 1.2mm 50A/LT101-151
16	IVB0661	PR0116	Extended electrode Plasma LT101;加长等离子电极 LT101
17	IVZ0695		Plasma torch head LT101;等离子枪头 LT101
17a	IFT0686	EA0131	“O”ring Φ 18.77x1.78mm in silicon;O型圈 Φ 18.77x1.78mm/硅胶
17b	IVF9006		Front insulator/LT101;枪颈前端绝缘圈 LT101
18	IGV0035		Plasma handle manual/A Series/Red;等离子手工手柄/A系列/红色
19	IHJ0722		Protection part/Plasma/Yellow;开关保护档片/等离子用/黄色
20	IHQ0070	185.0031	Trigger;开关
21	IHJ0894		Joint/big/new type;球节套件/大/新式
22			Cable assembly;电缆组
22.1	IVN00210066-00		Cable assembly/LT100-101/10MMQ/6M ATT. 1/8G;电缆组/LT100-101/10MMQ/6M ATT. 1/8G
22.2	IVN00210060-00		Cable assembly/LT100-101/10MMQ/6M center adaptor;电缆组/LT100-101/10MMQ/6M 中央插头
22.3	IVN10210066-00		Cable assembly/LTM100-101/10MMQ/6M ATT. 1/8G;电缆组/LT100-101/10MMQ/6M ATT. 1/8G
22.4	IVN10210060-00		Cable assembly/LTM100-101/10MMQ/6M center adaptor;电缆组/LT100-101/10MMQ/6M 中央插头
22.5	IVN0631		Cable assembly/LT100-101/6M/central adaptor;电缆组/LT100-101/6m/中央插头
23	ICG6006		Spanner for Plasma;等离子枪扳手
24	IVZ0665		Plasma torch head LTM101;等离子枪头 LTM101
24a	IGV0013	W0300144	Fiber glass position tube/LTM;自动枪手柄 LTM
25			Adaptor;接头
25.1	IZT5687		Connecting adaptor 1/8G-1/4G;转换接头1/8G-1/4G
25.2	IZT5686		Connecting adaptor 1/8G-3/8G;转换接头1/8G-3/8G
25.3	IZT5688		Connecting adaptor 1/8G-M14×1;转换接头1/8G-M14×1
25.4	IZT5689		Connecting adaptor 1/8G-M16×1.5;转换接头1/8G-M16×1.5
25.5	IZX0078	FY0023	Central adaptor torch side Plasma 5 pins;等离子中央插头/5针
26	ISM0077	CV0022	Circle cutting attachment/LT100-151; 圆周切割附件 LT100-151
26.1	ISM0076		Wheel spacer with spanner LT100-101;滚轮支架 LT100-101/带扳手

LT141/LTM141-A



WITH HIGH FREQUENCY
高频

MACHINE TORCH
自动枪

26a
26

27.1 1/4G
27.2 3/8G
27.3 M14X1
27.4 M16X1.5
27.5 Central adaptor
中央插头

25

28

28.1

Technical Data	技术参数
Current 额定电流	140 Amp
Duty Cycle 占载率	60%
Gas 气体	AIR 空气
Gas Pressure 气压	4.5-5.0 Bar
Gas Flow 气流量	220LPM
Ignition 引弧方式	HF 高频
Post Flow 气体延时	140sec. recommended 推荐140秒
Standard Length 标准长度	6M

Note: About the registered trade mark, reference number of the model of the machine and spare parts, please see inner cover (company introduction)
注:关于注册商标、机器及配件的参考编号的注解, 请见封面内页 (公司简介)

LT141/LTM141-A



HAND TORCH

Code	Ref.	Description	Code	Ref.	Description
IVT6507	PA1502	Plasma cutting torch LT141/6m 1/4G; 等离子切割枪/LT141/6m/1/4G	IVT6508		Plasma cutting torch LT141/12m 1/4G; 等离子切割枪/LT141/12m/1/4G
IVT6501		Plasma cutting torch LT141/6m 3/8G; 等离子切割枪/LT141/6m/3/8G	IVT6502		Plasma cutting torch LT141/12m 3/8G; 等离子切割枪/LT141/12m/3/8G
IVT6500	PA1500	Plasma cutting torch LT141/6m M14 x 1; 等离子切割枪/LT141/6m/M14 x 1	IVT6506	PA1501	Plasma cutting torch LT141/12m M14 x 1; 等离子切割枪/LT141/12m/M14 x 1
IVT6504		Plasma cutting torch LT141/6m M16 x 1.5; 等离子切割枪/LT141/6m/M16 x 1.5	IVT6560		Plasma cutting torch LT141/12m M16 x 1.5; 等离子切割枪/LT141/12m/M16 x 1.5
IVT6509	PA1504	Plasma cutting torch LT141/6m central adaptor; 等离子切割枪/LT141/6m/ 中央插头	IVT6505	PA1505	Plasma cutting torch LT141/12m central adaptor; 等离子切割枪/LT141/12m/ 中央插头

MACHINE TORCH

Code	Ref.	Description	Code	Ref.	Description
IVT0603		Plasma cutting atuo torch LTM141/6m 3/8G; 等离子自动切割枪/LTM141/6m/3/8G	IVT0601		Plasma cutting atuo torch LTM141/12m 1/4G; 等离子自动切割枪/LTM141/12m/1/4G
IVT0605		Plasma cutting atuo torch LTM141/6m 1/4G; 等离子自动切割枪/LTM141/6m/1/4G	IVT0604		Plasma cutting atuo torch LTM141/12m 3/8G; 等离子自动切割枪/LTM141/12m/3/8G
IVT0608	PA0103	Plasma cutting atuo torch LTM141/6m M14 x 1; 等离子自动切割枪/LTM141/6m/M14 x 1	IVT0609	PA0104	Plasma cutting atuo torch LTM141/12m M14 x 1; 等离子自动切割枪/LTM141/12m/M14 x 1
IVT0695	PA0145	Plasma cutting atuo torch LTM141/6m central adaptor; 等离子自动切割枪/LTM141/6m/ 中央插头	IVT0691	PA0146	Plasma cutting atuo torch LTM141/12m central adaptor; 等离子自动切割枪/LTM141/12m/ 中央插头
IVT0697		Plasma cutting atuo torch LTM141/6m M16 x 1.5; 等离子自动切割枪/LTM141/6m/M16 x 1.5	IVT0698		Plasma cutting atuo torch LTM141/12m M16 x 1.5; 等离子自动切割枪/LTM141/12m/M16 x 1.5

Position	Code	Ref.	Description
(带 "●" 为标准配置 / With "●" is the standard configuration)			
1	ISM0068	CV0013	Gouging spacer/LT141-150; 弧口凿支架 LT141-150
2	ISM0069	CV0014	Four pointed spacer/LT100-150; 四点支架 LT100-150
3	ISM0067	CV0012	Double pointed spacer/LT100-150; 两点支架 LT100-150
●4	ISM0066	CV0011	Spacer spring LT100-150; 隔离环 LT100-150
●5	IVS0607-05	PC0102	Outside nozzle LT141; 外喷嘴 LT141
6	ISM0084	CV0039	Four point crown shield with insulator/LT101-141; 四点支架/带绝缘环 LT101-141
7	ISM0078	CV0023	Spacer for contact cutting/LT101-141; 隔离支架/接触切割 LT101-141
8	IVS0686-05	PC0131	Outside nozzle LT141-151; 外喷嘴 LT141-151
9			Tip; 喷嘴
9.1	IVU0606-11	PD0101-11	Tip Φ 1.1mm/ LT101-141; 喷嘴 Φ 1.1mm/ LT101-141
9.2	IVU0606-14	PD0101-14	Tip Φ 1.4mm/ LT101-141; 喷嘴 Φ 1.4mm/ LT101-141
●9.3	IVU0606-17	PD0101-17	Tip Φ 1.7mm/ LT101-141; 喷嘴 Φ 1.7mm/ LT101-141
9.4	IVU0606-19	PD0101-19	Tip Φ 1.9mm/ LT101-141; 喷嘴 Φ 1.9mm/ LT101-141
●10	IVF0606	PE0101	Diffuser LT101-141; 分流器 LT101-141
●11	IVB0606	PR0101	Electrode Plasma LT101-141; 等离子电极 LT101-141
12	IZN0518		Air tube/LT141-151; 导流管 LT101-141
13	ISM0099		Locking nut; 锁紧螺母
14	ISM0003	CV0008	Contact cutting attachment/LT100-151; 接触切割保护帽 LT100-151
15	ISM0004	CV0009	Long contact cutting attachment/LT100-151; 加长接触切割保护帽 LT100-151
16			Tip; 喷嘴
16.1	IVU0662-14	PD0117-14	Extended tip Φ1.4mm/LT101-151; 加长喷嘴 Φ1.4mm/ LT101-151
16.2	IVU0662-17	PD0117-17	Extended tip Φ1.7mm/LT101-151; 加长喷嘴 Φ1.7mm/ LT101-151
16.3	IVU0662-19	PD0117-19	Extended tip Φ1.9mm/LT101-151; 加长喷嘴 Φ1.9mm/ LT101-151
16.4	IVU0666	PD0111	Extended tip Φ1.2mm 50A/LT101-151; 加长喷嘴 Φ1.2mm 50A/LT101-151
17	IVF0608	PE0103	Diffuser LT151; 分流器 LT151
18	IVB0661	PR0116	Extended electrode Plasma LT101/141; 加长等离子电极 LT101/141
19	IVZ0655		Plasma torch head LT141; 等离子枪头 LT141
19a	IFT0686	EA0131	"O"ring Φ 18.77x1.78mm in silicon; O型圈 Φ 18.77x1.78mm/硅胶
19b	IVF9007		Front insulator/LT141-151; 枪颈前端绝缘圈 LT141-151
20	IGV0035		Plasma handle manual/A Series/Red; 等离子手工手柄/A系列/红色
21	IHJ0722		Protection part/Plasma/Yellow; 开关保护档片/等离子用/黄色
22	IHQ0070	185.0031	Trigger; 开关
23	IHJ0894		Joint/big/new type; 球节套件/大/新式
24			Cable assembly; 电缆组
24.1	IVN00316060-00		Cable assembly/LT141-151/16MMQ/6M CENTER ADAPTOR; 电缆组/LT141-151/16MMQ/6M 中央插头
24.2	IVN00316066-00		Cable assembly/LT141-151/16MMQ/6M ATT. 1/8G; 电缆组/LT141-151/16MMQ/6M ATT. 1/8G
24.3	IVN10316060-00		Cable assembly/LTM141-151/16MMQ/6M CENTER ADAPTOR; 电缆组/LTM141-151/16MMQ/6M 中央插头
24.4	IVN10316066-00		Cable assembly/LTM141-151/16MMQ/6M ATT. 1/8G; 电缆组/LTM141-151/16MMQ/6M ATT. 1/8G
25	ICG6006		Spanner for Plasma; 等离子枪扳手
26	IVZ0607		Plasma torch head LTM141; 等离子枪头 LTM141
26a	IGV0013	W0300144	Fiber glass position tube/LTM; 自动枪手柄 LTM
27			Adaptor; 接头
27.1	IZT5687		Connecting adaptor 1/8G-1/4G; 转换接头1/8G-1/4G
27.2	IZT5686		Connecting adaptor 1/8G-3/8G; 转换接头1/8G-3/8G
27.3	IZT5688		Connecting adaptor 1/8G-M14x1; 转换接头1/8G-M14x1
27.4	IZT5689		Connecting adaptor 1/8G-M16x1.5; 转换接头1/8G-M16x1.5
27.5	IZX0078	FY0023	Central adaptor torch side Plasma 5 pins; 等离子中央插头/5针
28	ISM0077	CV0022	Circle cutting attachment/LT100-151; 圆周切割附件LT100-151
28.1	ISM0076		Wheel spacer with spanner LT100-101; 滚轮支架 LT100-101/带扳手

Note: About the registered trade mark, reference number of the model of the machine and spare parts, please see inner cover (company introduction)
注:关于注册商标、机器及配件的参考编号的注解, 请见封面内页 (公司简介)

LT150/LTM150-CB



WITH HIGH FREQUENCY
高频

MACHINE TORCH
自动枪

27.1 1/4G

27.2 3/8G

27.3 M14X1

27.4 M16X1.5

27.5 Central adaptor
中央插头

28

Technical Data	技术参数
Current 额定电流	150 Amp
Duty Cycle 占载率	60%
Gas 气体	AIR 空气
Gas Pressure 气压	4.5-5.0 Bar
Gas Flow 气流量	220LPM
Ignition 引弧方式	HF 高频
Post Flow 气体延时	150sec. recommended 推荐150秒
Standard Length 标准长度	6M

LT150/LTM150-CB



HAND TORCH

Code	Ref.	Description	Code	Ref.	Description
IVT6820		Plasma cutting torch LT150/6m 1/8G;等离子切割枪/LT150/6m 1/8G	IVT6830		Plasma cutting torch LT150/12m 1/8G;等离子切割枪/LT150/12m 1/8G
IVT6826		Plasma cutting torch LT150/6m 1/4G;等离子切割枪/LT150/6m 1/4G	IVT6836		Plasma cutting torch LT150/12m 1/4G;等离子切割枪/LT150/12m 1/4G
IVT6827	1576	Plasma cutting torch LT150/6m central adaptor;等离子切割枪/LT150/6m/中央插头	IVT6837		Plasma cutting torch LT150/12m central adaptor;等离子切割枪/LT150/12m/中央插头
IVT6828		Plasma cutting torch LT150/6m M16 x 1.5;等离子切割枪/LT150/6m/M16 x 1.5	IVT6838		Plasma cutting torch LT150/12m M16 x 1.5;等离子切割枪/LT150/12m/M16 x 1.5
IVT6829		Plasma cutting torch LT150/6m M14 x 1;等离子切割枪/LT150/6m/M14 x 1	IVT6839		Plasma cutting torch LT150/12m M14 x 1;等离子切割枪/LT150/12m/M14 x 1

MACHINE TORCH

Code	Ref.	Description	Code	Ref.	Description
IVT6731		Plasma cutting auto torch LTM150/6m M16 x 1.5;等离子自动切割枪/LTM150/6m/M16 x 1.5	IVT6881		Plasma cutting auto torch LTM150/12m M16 x 1.5;等离子自动切割枪/LTM150/12m/M16 x 1.5
IVT6735	1577	Plasma cutting auto torch LTM150/6m central adaptor;等离子自动切割枪/LTM150/6m/中央插头	IVT6885		Plasma cutting auto torch LTM150/12m central adaptor;等离子自动切割枪/LTM150/12m/中央插头
IVT6737		Plasma cutting auto torch LTM150/6m 1/4G;等离子自动切割枪/LTM150/6m 1/4G	IVT6887		Plasma cutting auto torch LTM150/12m 1/4G;等离子自动切割枪/LTM150/12m 1/4G
IVT6738		Plasma cutting auto torch LTM150/6m M14 x 1;等离子自动切割枪/LTM150/6m/M14 x 1	IVT6888		Plasma cutting auto torch LTM150/12m M14 x 1;等离子自动切割枪/LTM150/12m/M14 x 1
IVT6739	1529	Plasma cutting auto torch LTM150/6m 1/8G;等离子自动切割枪/LTM150/6m 1/8G	IVT6889		Plasma cutting auto torch LTM150/12m 1/8G;等离子自动切割枪/LTM150/12m 1/8G

Position	Code	Ref.	Description
(带“●”为标准配置 / With “●” is the standard configuration)			
1	ISM0068	1406	Gouging spacer/LT141-150; 气刨支架LT141-150
2	ISM0069	W0300177	Four pointed spacer/LT100-150;四点支架/LT100-150
3	ISM0067	1408 / W0300131	Double pointed spacer/LT100-150; 两点支架/LT100-150
● 4	ISM0066	1386 / W0300130	Spacer spring/LT100-150;隔离簧/LT100-150
● 5	IVS0007-05	1389	Outside nozzle LT150; 外喷嘴 LT150
6			Tip;喷嘴
6.1	IVU0071-11	1371	Tip Φ1.1mm LT100-150;喷嘴 Φ1.1mm/LT100-150
6.2	IVU0071-13	1372	Tip Φ1.3mm LT100-150;喷嘴 Φ1.3mm/LT100-150
6.3	IVU0071-16	1373	Tip Φ1.6mm LT100-150;喷嘴 Φ1.6mm/LT100-150
● 6.4	IVU0071-18	1374	Tip Φ1.8mm LT100-150;喷嘴 Φ1.8mm/LT100-150
7	ISM0099	W0300184	Locking nut;锁紧螺母
8	ISM0083	W0300180	Spacer for contact cutting/LT100-150;隔离支架/接触切割 LT100-150
9	IVS0089-05		Contact cutting nozzle LT150; 接触式外喷嘴 LT150
10			Tip;喷嘴
10.1	IVU0073-14	W0300135	Flat tip Φ1.35mm/LT100-150;喷嘴 Φ1.35mm/LT100-150
10.2	IVU0073-16	W0300137	Flat tip Φ1.6mm/LT100-150;喷嘴 Φ1.6mm/LT100-150
10.3	IVU0073-18		Flat tip Φ1.8mm/LT100-150;喷嘴 Φ1.8mm/LT100-150
● 11	IVF0004	1377 / W0300124	Diffuser LT100-150; 分流器 LT100-150
● 12	IVB0089	1376 / W0300123	Electrode HF LT100-150;等离子电极/HF/LT100-150
● 13	IZN0768	1378	Air tube LT141-151; 导流管 LT141-151
14	ISM0003	W0300182	Contact cutting attachment/LT100-150; 接触切割保护帽/LT100-150
15	ISM0004	W0300183	Long contact cutting attachment/LT100-150; 加长接触切割保护帽/LT100-150
16			Tip;喷嘴
16.1	IVU0075-14	W0300178	Extended tip Φ1.4mm/LT100-150;加长喷嘴 Φ1.4mm/LT100-150
16.2	IVU0075-16	W0300179	Extended tip Φ1.6mm/LT100-150;加长喷嘴 Φ1.6mm/LT100-150
16.3	IVU0075-18		Extended tip Φ1.8mm/LT100-150;加长喷嘴 Φ1.8mm/LT100-150
16.4	IVU0080-11	1369 / W0300134	Contact Extended tip 50A/LT100-150; 加长接触喷嘴 50A/LT100-150
17	IVB0095	1517 / W0300133	Extended electrode HF Plasma LT100-150; 加长等离子电极 HF/LT100-150
18	IZN0764		Extended air tube/LT150; 加长导流管 LT150
19	IVZ0030		Plasma torch head/LT150等离子枪头 LT150
19a	IFT0689	1398 / W0300121	"O"ring LT150; O型圈 LT150
19b	IVF9007		Front insulator LT141-151; 枪颈前端绝缘圈 LT141-151
20	IGV0035		Plasma handle manual/A Series/Red;等离子手工手柄/A系列/红色
21	IHJ0722		Protection part/Plasma/Yellow;开关保护档片/等离子用/黄色
22	IHQ0070	185.0031	Trigger;开关
23	IHJ0894		Joint/big/new type;球节套件/大/新式
24			Cable assembly;电缆组
24.1	IVN00316060-00		Cable assembly/LT141-151/16MMQ/6M center adaptor;电缆组/LT141-151/16MMQ/6M 中央插头
24.2	IVN00316066-00		Cable assembly/LT141-151/16MMQ/6M ATT.1/8G;电缆组/LT141-151/16MMQ/6M ATT.1/8G
24.3	IVN10316060-00		Cable assembly/LTM141-151/16MMQ/6M center adaptor;电缆组/LTM141-151/16MMQ/6M 中央插头
24.4	IVN10316066-00		Cable assembly/LTM141-151/16MMQ/6M ATT.1/8G;电缆组/LTM141-151/16MMQ/6M ATT.1/8G
25	ICG6006		Spanner for Plasma;等离子枪扳手
26	IVZ0089	1354	Plasma torch head LTM150;等离子枪头 LTM150
26a	IGV0013		Fiber glass position tube/LTM;自动枪手柄 LTM
27			Adaptor;接头
27.1	IZT5687		Connecting adaptor 1/8G-1/4G;转换接头1/8G-1/4G
27.2	IZT5688		Connecting adaptor 1/8G-M14x1;转换接头1/8G-M14x1
27.3	IZT5689		Connecting adaptor 1/8G-M16x1.5;转换接头1/8G-M16x1.5
27.4	IZX0078		Central adaptor torch side Plasma 5 pins;等离子中央插头/5针
28	ISM0077		Circle cutting attachment/LT100-151; 圆周切割附件 LT100-151
28.1	ISM0076		Wheel spacer with spanner LT100-101;滚轮支架 LT100-101/带扳手

LT151/LTM151-A



WITH HIGH FREQUENCY
高频

MACHINE TORCH
自动枪

23a
23

24.1 1/4G
24.2 3/8G
24.3 M14X1
24.4 M16X1.5
24.5 Central adaptor
中央插头

Technical Data	技术参数
Current 额定电流	150 Amp
Duty Cycle 占载率	60%
Gas 气体	AIR 空气
Gas Pressure 气压	4.5-5.0 Bar
Gas Flow 气流量	220LPM
Ignition 引弧方式	HF 高频
Post Flow 气体延时	150sec. recommended 推荐150秒
Standard Length 标准长度	6M

25.1

LT151/LTM151-A



HAND TORCH

Code	Ref.	Description	Code	Ref.	Description
IVT6550	PA1550	Plasma cutting torch LT151/6m M14 × 1;等离子切割枪/LT151/6m/M14 × 1	IVT6556		Plasma cutting torch LT151/12m M14 × 1;等离子切割枪/LT151/12m/M14 × 1
IVT6551		Plasma cutting torch LT151/6m 3/8G;等离子切割枪/LT151/6m 3/8G	IVT6552		Plasma cutting torch LT151/12m 3/8G;等离子切割枪/LT151/12m 3/8G
IVT6553		Plasma cutting torch LT151/6m M16 × 1.5;等离子切割枪/LT151/6m/M16 × 1.5	IVT6554		Plasma cutting torch LT151/12m M16 × 1.5;等离子切割枪/LT151/12m/M16 × 1.5
IVT6557		Plasma cutting torch LT151/6m 1/4G;等离子切割枪/LT151/6m 1/4G	IVT6558		Plasma cutting torch LT151/12m 1/4G;等离子切割枪/LT151/12m 1/4G
IVT6559	PA1554	Plasma cutting torch LT151/6m central adaptor;等离子自动切割枪/LT151/6m/中央插头	IVT6555		Plasma cutting torch LT151/12m central adaptor;等离子切割枪/LT151/12m/中央插头

MACHINE TORCH

Code	Ref.	Description	Code	Ref.	Description
IVT0759		Plasma cutting auto torch LTM151/6m 1/4G;等离子自动切割枪/LT151/6m 1/4G	IVT0755		Plasma cutting auto torch LTM151/12m 1/4G;等离子自动切割枪/LT151/12m 1/4G
IVT0751		Plasma cutting auto torch LTM151/6m 3/8G;等离子自动切割枪/LT151/6m 3/8G	IVT0752		Plasma cutting auto torch LTM151/12m 3/8G;等离子自动切割枪/LT151/12m 3/8G
IVT0672	PA0127	Plasma cutting auto torch LTM151/6m M14 × 1;等离子自动切割枪/LT151/6m/M14 × 1	IVT0673		Plasma cutting auto torch LTM151/12m M14 × 1;等离子自动切割枪/LT151/12m/M14 × 1
IVT0753		Plasma cutting auto torch LTM151/6m M16 × 1.5;等离子自动切割枪/LT151/6m/M16 × 1.5	IVT0754		Plasma cutting auto torch LTM151/12m M16 × 1.5;等离子自动切割枪/LT151/12m/M16 × 1.5
IVT0757		Plasma cutting auto torch LTM151/6m central adaptor;等离子自动切割枪/LT151/6m/中央插头	IVT0758		Plasma cutting auto torch LTM151/12m central adaptor;等离子自动切割枪/LT151/12m/中央插头

Position	Code	Ref.	Description
(带“●”为标准配置 / With “●” is the standard configuration)			
1	ISM0059		Gouging spacer/LT151; 气刨支架/LT151
2	ISM0094		Spacer spring for ISM0093;隔离簧/配合 ISM0093
3	ISM0093		Spring holder protection nut;隔离环固定保护螺母
4	IVS0688-05	PC0131	Outside nozzle LT141-151;外喷嘴 LT141-151
●5	ISM6605	CV1105	Spacer/LT151;隔离簧/LT151
●6	IHJ0684		Nozzle shield/LT151;外喷嘴保护帽/LT151
●7	IVS0670-05	PC0120	Outside nozzle LT151;外喷嘴/LT151
8			Tip;喷嘴
8.1	IVU0604-14	PD0109-14	Tip Φ1.4mm LT151; 喷嘴 Φ1.4mm/LT151
8.2	IVU0604-16	PD0109-16	Tip Φ1.6mm LT151; 喷嘴 Φ1.6mm/LT151
●8.3	IVU0604-18	PD0109-18	Tip Φ1.8mm LT151; 喷嘴 Φ1.8mm/LT151
8.4	IVU0604-30	PD0109-30	Tip Φ3.0mm LT151; 喷嘴 Φ3.0mm/LT151
●9	IVF0608	PE0103	Diffuser LT141/151;分流器 LT141/151
●10	IVB0666	PR0111	Electrode Plasma LT151; 等离子电极 LT151
●11	IZN0518		Air tube/LT141/151; 导流管 LT141/151
12	ISM0099		Locking nut;锁紧螺母
13	ISM0003	CV0008	Contact cutting attachment/LT100-151;接触切割保护帽 LT100-151
14	ISM0004	CV0009	Long contact cutting attachment/LT100-151;长接触切割保护帽 LT100-151
15			Tip;喷嘴
15.1	IVU0662-14	PD0117-14	Extended tip Φ1.4mm/LT101-151; 加长喷嘴 Φ1.4mm/LT101-151
15.2	IVU0662-17	PD0117-17	Extended tip Φ1.7mm/LT101-151; 加长喷嘴 Φ1.7mm/LT101-151
15.3	IVU0662-19	PD0117-19	Extended tip Φ1.9mm/LT101-151; 加长喷嘴 Φ1.9mm/LT101-151
15.4	IVU0666	PD0111	Extended tip 50A/LT101-151;加长喷嘴 50A/LT101-151
16	IVB0661	PR0116	Extended electrode Plasma LT101-151;加长等离子电极 LT101-151
17	IVZ0610		Plasma torch head LT151;等离子枪头 LTM151
17a	IFT0686	EA0131	“O”ring Φ18.77 x 1.78mm in silicon;O型圈 Φ18.77x1.78mm/硅胶
17b	IVF9007		Front insulator/LT141-151;枪颈前端绝缘圈 LT141-151
18	IGV0035		Plasma handle manual/A Series/Red;等离子手工手柄/A系列/红色
19	IHJ0722		Protection part/Plasma/Yellow;开关保护档片/等离子用/黄色
20	IHQ0070	185.0031	Trigger;开关
21	IHJ0894		Joint/big/new type;球节套件/大/新式
22			Cable assembly;电缆组
22.1	IVN00316060-00		Cable assembly/LT141-151/16MQ/6M center adaptor;电缆组/LT141-151/16MMQ/6M中央插头
22.2	IVN00316066-00		Cable assembly/LT141-151/16MQ/6M ATT.1/8G;电缆组/LT141-151/16MMQ/6M ATT.1/8G
22.3	IVN10316060-00		Cable assembly/LTM141-151/16MQ/6M center adaptor;电缆组/LTM141-151/16MMQ/6M中央插头
22.4	IVN10316066-00		Cable assembly/LTM141-151/16MQ/6M ATT.1/8G;电缆组/LTM141-151/16MMQ/6M ATT.1/8G
22.5	IVN0699		Cable assembly/LT141-151/6M central adaptor;电缆组/LT141-151/6m/中央插头
23	IVZ0666	PF0111	Plasma torch head LTM151;等离子枪头 LTM151
23a	IGV0013		Fiber glass position tube/LTM;自动枪手柄 LTM
24			Adaptor;接头
24	IZT5687		Connecting adaptor 1/8G-1/4G;转换接头1/8G-1/4G
24.1	IZT5686		Connecting adaptor 1/8G-3/8G;转换接头1/8G-3/8G
24.2	IZT5688		Connecting adaptor 1/8G-M14×1;转换接头1/8G-M14×1
24.3	IZT5689		Connecting adaptor 1/8G-M16×1.5;转换接头1/8G-M16×1.5
24.4	IZX0078	FY0023	Central adaptor torch side Plasma 5 pins;等离子中央插头/5针
25	ISM0077	CV0022	Circle cutting attachment/LT100-151;圆周切割附件 LT100-151
25.1	ISM0076		Wheel spacer with spanner LT100-101;滚轮支架 LT100-101/带扳手



WITH HIGH FREQUENCY
高频

MACHINE TORCH
自动枪

Technical Data	技术参数
Current 额定电流	100Amp
Duty Cycle 占载率	60%
Gas 气体	AIR 空气
Gas Pressure 气压	4.5-5.0 Bar
Gas Flow 气流量	220LPM
Ignition 引弧方式	HF 高频
Post Flow 气体延时	80 sec. recommended 推荐80秒
Standard Length 标准长度	5M

Note: About the registered trade mark, reference number of the model of the machine and spare parts, please see inner cover (company introduction)
注:关于注册商标、机器及配件的参考编号的注解, 请见封面内页 (公司简介)



HAND TORCH

Code	Ref.	Description
IVT0647		Plasma Cutting Torch/P80/10mmq/5m CENTER ADAPTOR; 等离子切割枪/P80/10mmq/5m 中央插头
IVT0646		Plasma Cutting Torch/P80/10mmq/5m 3/8G; 等离子切割枪/P80/10mmq/5m 3/8G
IVT0985		Plasma Cutting Torch/P80/10mmq/5m M16x1.5; 等离子切割枪/P80/10mmq/5m M16x1.5
IVT0981		Plasma Cutting Torch/P80/10mmq/5m 1/4G; 等离子切割枪/P80/10mmq/5m 1/4G
IVT0982		Plasma Cutting Torch/P80/10mmq/5m M14x1.5; 等离子切割枪/P80/10mmq/5m M14x1.5
IVT8102		Plasma Cutting Torch/P80/14mmq/5m M16x1.5; 等离子切割枪/P80/14mmq/5m M16x1.5
IVT8103		Plasma Cutting Torch/P80/12mmq/5m M16x1.5; 等离子切割枪/P80/12mmq/5m M16x1.5

MACHINE TORCH

Code	Ref.	Description
IVT0100		Plasma auto torch/PP80/5M 1/4G; 等离子自动切割枪/PP80/5米 1/4G
IVT0106		Plasma auto torch/PP80/5M 3/8G; 等离子自动切割枪/PP80/5米 3/8G
IVT0107		Plasma auto torch/PP80/5M M14*1.5; 等离子自动切割枪/PP80/5米 M14*1.5
IVT0108		Plasma auto torch/PP80/5M M16*1.5; 等离子自动切割枪/PP80/5米 M16*1.5
IVT0109		Plasma auto torch/PP80/5M center adaptor; 等离子自动切割枪/PP80/5米 中央插头

Position	Code	Ref.	Description
(带“●”为标准配置 / With “●” is the standard configuration)			
●1	ISM0709		Isolated Wheel/P80; 隔离滚轮/P80
●2	IVS0013	TGN02004	Ceramic Outside Nozzle/P80; 陶瓷外喷嘴/P80
3			Tip; 喷嘴
3.1	IVU0039-10	TET01110	Tip Φ1.0mm/P80; 电极喷嘴 Φ1.0mm/P80
3.2	IVU0039-13	TET01130	Tip Φ1.3mm/P80; 电极喷嘴 Φ1.3mm/P80
●3.3	IVU0039-15	TET01512	Tip Φ1.5mm/P80; 电极喷嘴 Φ1.5mm/P80
●3.4	IVU0039-17		Tip Φ1.7mm/panasonic P80; 喷嘴 Φ1.7mm/松下P80
●4	IVB0020	TET02033	Electrode/P80; 电极/P80
●5	IVZ0093	TKU08103	Plasma Torch Head P80/light; 等离子枪头/P80/轻型
6	IGV0035		Plasma Handle Manuale/ASeires/Red; 等离子手柄/A系列/红色
7	IHJ0722		Protection part/Plasma/Yellow; 开关保护档片/等离子用/黄色
8	IHQ0700		Trigger; 开关
9	IHJ0893		Joint/small/new type; 球 节套件/小/新式
10			Cable assembly; 电缆组
10.1	IVN00810050-00		Cable assembly/P80/10MMQ/5M center adaptor; 电缆组/P80/10MMQ/5M 中央插头
10.2	IVN00810051-00		Cable assembly/P80/10MMQ/5M ATT.1/4G; 电缆组/P80/10MMQ/5M ATT.1/4G
10.3	IVN00810052-00		Cable assembly/P80/10MMQ/5M ATT.3/8G; 电缆组/P80/10MMQ/5M ATT.3/8G
10.4	IVN00810054-00		Cable assembly/P80/10MMQ/5M M14 × 1.5; 电缆组/P80/10MMQ/5M M14*1.5
10.5	IVN00810055-00		Cable assembly/P80/10MMQ/5M M16 × 1.5; 电缆组/P80/10MMQ/5M M16*1.5
10.6	IVN10810050-00		Cable assembly/PP80/10MMQ/5M center adaptor; 电缆组/PP80/10MMQ/5M 中央插头
10.7	IVN10810051-00		Cable assembly/PP80/10MMQ/5M ATT.1/4G; 电缆组/PP80/10MMQ/5M ATT.1/4G
10.8	IVN10810052-00		Cable assembly/PP80/10MMQ/5M ATT.3/8G; 电缆组/PP80/10MMQ/5M ATT.3/8G
10.9	IVN10810054-00		Cable assembly/PP80/10MMQ/5M M14 × 1.5; 电缆组/PP80/10MMQ/5M M14*1.5
10.10	IVN10810055-00		Cable assembly/PP80/10MMQ/5M M16 × 1.5; 电缆组/PP80/10MMQ/5M M16*1.5
11	IHQ0757		Connector 2 PINS/F; 两芯航插
12	IHJ0029		Protection nut CH19; 防触电保护套 CH19
13	ICG6009		Spanner for P80; P80枪用扳手
14	IVZ0070		Plasma machine torch head P80; P80等离子自动枪头
14a	IGV0705		Fiberglass position tube/LTM torch; 自动枪手柄/LTM/尼龙

Note: About the registered trade mark, reference number of the model of the machine and spare parts, please see inner cover (company introduction)
注:关于注册商标、机器及配件的参考编号的注解, 请见封面内页 (公司简介)



Technical Data		技术参数	
Current 额定电流		30Amp	
Duty Cycle 占载率		60%	
Gas 气体		AlR 空气	
Gas Pressure 气压		4.5~5.0 Bar	
Gas Flow 气流量		150LPM	
Ignition 引弧方式		HF高频	
Post Flow 气体延时		40sec. recommended 推荐40秒	
Standard Length 标准长度		5M	

HAND TORCH

Code	Ref.	Description
IVT6650		Plasma torch/PT31/5M M16*1.5;等离子切割枪/PT31/5米/M16*1.5
IVT6250		Plasma torch/PT31/5M M16*1.5/E;等离子切割枪/PT31/5米/M16*1.5/经济型

[illegible]



WITH HIGH FREQUENCY
高频

Technical Data	技术参数
Current 额定电流	50Amp
Duty Cycle 占载率	60%
Gas 气体	AIR 空气
Gas Pressure 气压	4.5-5.0 Bar
Gas Flow 气流量	155LPM
Ignition 引弧方式	HF 高频
Post Flow 气体延时	40sec. recommended 推荐40秒
Standard Length 标准长度	5M

Note: About the registered trade mark, reference number of the model of the machine and spare parts, please see inner cover (company introduction)
注:关于注册商标、机器及配件的参考编号的注解, 请见封面内页 (公司简介)



HAND TORCH

Code	Ref.	Description
IVT6620		Plasma torch/SG51 5M/M16*1.5;等离子切割枪/SG51 5米/M16*1.5
IVT6220		Plasma torch/SG51 5M M16*1.5/red body black rubber handle/E;等离子切割枪/SG51 5米/M16*1.5/红黑手柄/欧姆龙摆杆开关/经济型

Position	Code	Ref.	Description
(带“●”为标准配置 / With “●” is the standard configuration)			
●1	IVS0092		Outside nozzle SG51;外喷嘴 SG51
2			Tip ;电极喷嘴
●2.1	IVU0689-10		Tip Φ1.0mm SG51;电极喷嘴 Φ1.0mm SG51
2.2	IVU0689-12		Tip Φ1.2mm 30A;电极喷嘴 Φ1.2mm 30A
●3	IVF0074		Diffuser SG51;分流器 SG51
●4	IVB0093		Electrode SG51;电极/SG51
5	IVZ0033		Plasma torch head SG51;等离子枪头 SG51
6	IHQ0240		Switch/kit/SG51/SG55/P31;开关套件/SG51/SG55/P31
7	IGV0025		Label/TIG、PLASMA/ITC;手柄标签/用于IGV0685-01、IGV0025-01/TIG、PLASMA/ITC
8	IHJ0860		Small joint TIG 9-17-20;小球节 TIG 9-17-20
9	IHJ0868		Big spring support for TIG 18-26;大弹簧支撑 TIG18-26
10			Cable assembly;电缆组
10.1	IVN00606055-00		Cable assembly/SG51/SG55/6MMQ/5M M16*1.5;电缆组/SG51/SG55/6MMQ/5M M16*1.5
10.2	IVN00606055-98		Cable assembly/SG51/SG55/6MMQ/5M M16*1.5/E;电缆组/SG51/SG55/6MMQ/5M M16*1.5/经济型
11	IHQ0757		Connector 2 PINS/F;两芯航插
12	IHJ0029		Protection nut CH19;防触电保护套 CH19

Note: About the registered trade mark, reference number of the model of the machine and spare parts, please see inner cover (company introduction)
注:关于注册商标、机器及配件的参考编号的注解, 请见封面内页 (公司简介)



WITH HIGH FREQUENCY
高频

1 2 3 4 5 6 7 8 9 10 11 12

Technical Data	技术参数
Current 额定电流	60Amp
Duty Cycle 占载率	60%
Gas 气体	AIR 空气
Gas Pressure 气压	4.5-5.0 Bar
Gas Flow 气流量	160LPM
Ignition 引弧方式	HF 高频
Post Flow 气体延时	40sec. recommended 推荐40秒
Standard Length 标准长度	5M

Note: About the registered trade mark, reference number of the model of the machine and spare parts, please see inner cover (company introduction)
注:关于注册商标、机器及配件的参考编号的注解, 请见封面内页 (公司简介)



HAND TORCH

Code	Ref.	Description
IVT6610		Plasma torch/SG55/5M M16*1.5;等离子切割枪/SG55/5米/M16*1.5
IVT6210		Plasma torch/SG55/5M M16*1.5/E;等离子切割枪/SG55/5米/M16*1.5/红黑手柄/经济型

Position	Code	Ref.	Description
(带“●”为标准配置 / With “●” is the standard configuration)			
●1	IVS0076		Outside nozzle/ceramic/SG55;陶瓷外喷嘴/SG55
2			Tip ;电极喷嘴
2.1	IVU0680-09		Tip Φ0.9mm SG55;电极喷嘴 Φ1.0mm SG55
●2.2	IVU0680-10		Tip Φ1.0mm SG55;电极喷嘴 Φ1.0mm SG55
2.3	IVU0680-11		Tip Φ1.1mm SG55;电极喷嘴 Φ1.1mm SG55
2.4	IVU0680-12		Tip Φ1.2mm SG55;电极喷嘴 Φ1.2mm SG55
●3	IVB0086		Electrode/SG55;电极/SG55
4	IVZ0031		Plasma torch head SG55;等离子枪头 SG55
5	IHQ0240		Switch/kit/SG51/SG55/P31;开关套件/SG51/SG55/P31
6	IGV0025		Label/TIG、PLASMA/ITC;手柄标签/用于IGV0685-01、IGV0025-01/TIG、PLASMA/ITC
7	IHJ0860		Small joint TIG 9-17-20;小球节 TIG 9-17-20
8	IHJ0868		Big spring support for TIG 18-26;大弹簧支撑 TIG18-26
9			Cable assembly;电缆组
9.1	IVN00606055-00		Cable assembly/SG51/SG55/6MMQ/5M M16*1.5;电缆组/SG51/SG55/6MMQ/5M M16*1.5
9.2	IVN00606055-98		Cable assembly/SG51/SG55/6MMQ/5M M16*1.5/E;电缆组/SG51/SG55/6MMQ/5M M16*1.5/经济型
10	IHQ0757		Connector 2 PINS/F;两芯航插
11	IHJ0029		Protection nut CH19;防触电保护套 CH19
12	ICG6006		Spanner for plasma;PLASMA枪扳手

Note: About the registered trade mark, reference number of the model of the machine and spare parts, please see inner cover (company introduction)
注:关于注册商标、机器及配件的参考编号的注解, 请见封面内页 (公司简介)



WITH HIGH FREQUENCY
高频

Technical Data	技术参数
Current 额定电流	60Amp
Duty Cycle 占载率	60%
Gas 气体	AIR 空气
Gas Pressure 气压	4.5-5.0 Bar
Gas Flow 气流量	160LPM
Ignition 引弧方式	HF 高频
Post Flow 气体延时	40sec. recommended 推荐40秒
Standard Length 标准长度	5M



HAND TORCH

Code	Ref.	Description
IVT6630		Plasma torch/AG60/5M M16*1.5;等离子切割枪/AG60/5米/M16*1.5

Position	Code	Ref.	Description
(带“●”为标准配置 / With “●” is the standard configuration)			
●1	ISM0062		Spacer spring for SG55;隔离簧/SG55
2			Outside nozzle ;外喷嘴
●2.1	IVS0076-01		Outside nozzle with groove/ceramic/SG55/AG60;陶瓷外喷嘴/带卡槽/SG55/AG60
2.2	IVS0076		Outside nozzle/ceramic/SG55/AG60;陶瓷外喷嘴/SG55/AG60
3			Tip; 电极喷嘴
3.1	IVU0680-09		Tip Φ0.9mm SG55/AG60;电极喷嘴 Φ1.0mm SG55/AG60
●3.2	IVU0680-10		Tip Φ1.0mm SG55/AG60;电极喷嘴 Φ1.0mm SG55/AG60
3.3	IVU0680-11		Tip Φ1.1mm SG55/AG60;电极喷嘴 Φ1.1mm SG55/AG60
3.4	IVU0680-12		Tip Φ1.2mm SG55/AG60;电极喷嘴 Φ1.2mm SG55/AG60
4	IVB0086		Electrode/SG55/AG60;电极/SG55/AG60
5	IVZ0034		Plasma torch head AG60/with striking;等离子枪头 AG60/带引弧
6	IHQ0240		Switch/kit/SG51/SG55/P31;开关套件/SG51/SG55/P31
7	IGV0786		Plasma handle for SG51-55/PT31/AG60 torch/black rubber/OEM;SG51-55/PT31/AG60等离子手柄/黑色皮/OEM系列
8	IHJ0860		Small joint TIG 9-17-20;小球节 TIG 9-17-20
9	IHJ0868		Big spring support for TIG 18-26;大弹簧支撑 TIG18-26
10			Cable assembly;电缆组
10.1	IVN00706055-00		Cable assembly/AG60/6MMQ/5M M16*1.5;电缆组/AG60/6MMQ/5M M16*1.5
10.2	IVN00706055-98		Cable assembly/AG60/6MMQ/5M M16*1.5/E;电缆组/AG60/6MMQ/5M M16*1.5/经济型
11	IHQ0757		Connector 2 PINS/F;两芯航插
12	IHJ0029		Protection nut CH19;防触电保护套 CH19
13	ICG6006		Spanner for plasma;PLASMA枪扳手